


Art Table
AT 36", 48" & 60"

Assembly Instructions



How can we improve our assembly instructions?
Your comments and suggestions are important to us.
Please e-mail us at: support@versatables.com.


<p>1/4-20 Phillips Head Bolt</p>  <p>Qty:8</p>	<p>20mm Furniture Bolt</p>  <p>Qty:12</p>	<p>2" x 3/8" Hex Bolt</p>  <p>Qty:2</p>	<p>3/8" Washer</p>  <p>Qty:6</p>	<p>1/8" Nylock</p>  <p>Qty:2</p>
<p>10/24 x 1/2" Phillips Head Bolt</p>  <p>Qty:8</p>	<p>4mm Allen Wrench</p>  <p>Qty:1</p>	<p>Leveler / Glider</p>  <p>Qty:4</p>	<p>Zip Tie & Curly Tie</p>  <p>Qty:5</p>	
<p>Rubber Bumper</p>  <p>Qty:2</p>	<p>Main Surface</p>  <p>Qty:1</p>	<p>Cross Support</p>  <p>Qty:1</p>		
<p>Tilt Adjustment Mechanism</p>  <p>Qty:2</p>	<p>Kick Panel</p>  <p>Qty:1</p>	<p>Pencil Tray</p>  <p>Qty:1</p>		
<p>Side Leg Frame (L& R)</p>  <p>Qty:2</p>	<p>Angle Back Support</p>  <p>Not Included for the 36"</p> <p>Qty:1</p>	<p>Pencil Tray Lip</p>  <p>Qty:1</p>		
		<p>Cable Management Tray</p>  <p>Qty:1</p>		



Step 1

Levelers & Cable Management Tray


Attach Levelers and Cable Management Tray using (4) 20mm Furniture Bolts.



Step 2

Kick Panel

Attach kick panel to side leg frames using 20mm furniture bolts.



Step 3


Cross Support

Attach Cross Support to leg frames using (2) 20mm Furniture Bolts on each side. Make sure two sets of holes face to the front and two sets of holes face down to attach tilt adjustment.

20mm Furniture Bolt



Qty:4



20mm Furniture Bolt

Step 4

Attach LCD Holder

Attach pencil tray using (2) 3/8" Hex Bolts, (6) 3/8" Washers, and (2) 3/8" Nylocks on both sides.

3/8" Nylock



Qty:2

3/8" Washer



Qty:6

2" x 3/8" Hex Bolt



Qty:2



3/8" Nylock



3/8" Washer

2" x 3/8" Hex Bolt

Step 5



Main Platform Onto Pencil Tray

Attach Main Platform onto Pencil Tray and Pencil Tray Lip using 1/4-20 Phillips Head bolts.

1/4-20 Phillips Head Bolt



Qty:4



1/4 - 20 Phillips Head Bolts

Step 6


Tilt Mechanism

Attach the lower part of the Tilt Mechanism to the bottom of the Cross Support and the surface using (8) 10/24 x 1/2" Phillips Head Bolts.

10-24 x 1/2" Phillips Head Bolt



Qty:8



10/24 - 1/2" Phillips Head Bolts

Step 7

This step DOES NOT apply to AT36"


Angle Back Support

Attach Angle Back Support using (3) 1/4-20 Phillips Head Bolts.

1/4-20 Phillips Head Bolt



Qty:3



1/4 - 20 Phillips Head Bolts

Step 8

Rubber Bumper

Make sure the top surface of the Side Frames Top Tube is clean and dry. Stick the Rubber Bumper on top of the surfaces 1" to 3" from the back Edge of the other side Frame Top Tube as shown. Press down on the Rubber Bumpers to ensure proper adhesion.

Rubber Bumper



Qty:2



How can we improve our assembly instructions?
Your comments and suggestions are important to us.
Please e-mail us at: support@versatables.com.


VersaTable and GTCO Digitizer Assembly Guide

1. Assemble the VersaTable

To assemble the VersaTable, follow Steps 1 - 6 in the included VersaTable Assembly Guide, but skip Step 5. The Assembly Guide refers to the 'main surface'. However, the 'main surface' is not included because the GTCO Digitizer will act as the main surface. You will connect the GTCO Digitizer in Step 3 below.

2. Attach the Universal Mounting Brackets (UMB) to the VersaTable

- A. After completing Step 6 in the VersaTable Assembly Guide, you will now attach the other end of the Tilt Mechanism to the Angle Back Support. Insert a bolt, washer, and nut through the inner holes of the Tilt Mechanism and the corresponding holes of the Angle Back Support.
- B. Place the two UMBs perpendicular across the Pencil Tray and the Angle Back Support.
 - One UMB will go over the Pencil Tray slot that is farthest to the left.
 - The other UMB will go over the slot that is farthest to the right.
- C. Attach the UMBs to the Pencil Tray using two of the supplied bolts, washers, and nuts. Do not tighten.
- D. Attach the UMBs to the Angle Back Support and the outer holes of the Tilt Mechanism using two of the supplied bolts, washers, and nuts.
- E. Place the rubber bumpers on the Cross Support under the UMBs.
- F. Tighten all bolts.



3. Attach the GTCO Digitizer to the UMBs

The digitizer is attached to the UMBs with the four supplied Thumbscrews. The Thumbscrews are threaded through the holes in the end tabs on the UMBs and screwed into the sliding T-Nuts in the top and bottom channels of the Digitizer frame.

- A. Center the Digitizer over the UMBs.
- B. Slide the T-Nuts into place so they line up with the holes in the end tabs of the UMBs.
- C. Screw a Thumbscrew through each UMB end tab and into the receiver T-Nut.



Attached Kit Contents

6 x 1/4"-20x1" bolt

6 x 1/4" split lockwasher

6 x 1/4" flat washer

6 x 1/4"-20 nut

4 x Thumbscrews

